



AMSure® Foley Insertion Trays

AMSure Foley Insertion Trays improve simplicity and efficiency of care by providing the basic supplies required to safely insert a Foley catheter. **(HCPCS code A4310)**

- Deep tray basin designed to prevent contamination
- Gloves and povidone iodine swab sticks help maintain sterility and minimized risk of infection
- Sterile, DEHP-free, BPA-free, not manufactured with natural rubber latex

Peel-Top

Trays include: 1000 mL collection basin with peel-off paper top web, (1-pack of 3) Povidone-iodine swab sticks or benzalkonium chloride prep pad (3 total), vinyl powder-free gloves, waterproof underpad 13 in. x 18 in. (33.02 cm x 45.72 cm), lubrication jelly, fenestrated drape.

SWAB STICK	REF	PRE-FILLED SYRINGE	QTY/UNIT
PVP Swab Sticks	AS880	10 cc	20/Case
	AS890	30 cc	20/Case
BZK Swab Sticks	AS880K	10 cc	20/Case
	AS890K	30 cc	20/Case

CSR Wrapped

Trays include: 1000 mL collection basin, 500mm x 500mm CSR wrapped in header bag, (2-packs of 3) Povidone-iodine swab sticks (6 total), nitrile powder-free gloves, waterproof underpad 13 in. x 18 in. (33.02 cm x 45.72 cm), lubrication jelly, fenestrated drape.

SWAB STICK	REF	PRE-FILLED SYRINGE	QTY/UNIT
PVP Swab Sticks (2 packs of 3)	AS886	10 cc	20/Case
	AS896	30 cc	20/Case